

K1JJ 3-24-96

- * use copper strap for all R.F. connections.
- * Do NOT short plate

* KROOP PLANTS COIL CLEAR
OF ALL OTHER PLANTS,
ESP. TRANSFORMERS. .001

2 TURN
TEFLON WOUND
AROUND COIL
VERNIER
+5K

