

Notes:

1. The frequency is the phantom carrier/AM carrier frequency. You must be within 20 Hz.
Two years after inception, tolerance tightens to +/- 8 Hz.
2. SSB mode on this band is LSB only.
3. AM protection rule for SSB 'ers : You must be at least 3 channels above the AM carrier channel,
OR you must be at least 2 channels below the carrier channel.
4. A channel may not be used if already occupied.
5. To start AM operation, 4 consecutive channels must be found clear of activity.
AM carrier would be on second lowest of the 4 channels (center of 12 kHz.).

Channel #	Frequency	
1	3603	1st Extra Class channel.
2	3606	
3	3609	
4	3612	
5	3615	
6	3618	
7	3621	
8	3624	
9	3627	
10	3630	
11	3633	
12	3636	
13	3639	
14	3642	
15	3645	
16	3648	
17	3651	
18	3654	
19	3657	
20	3660	
21	3663	
22	3666	
23	3669	
24	3672	
25	3675	
26	3678	
27	3681	
28	3684	
29	3687	
30	3690	
31	3693	
32	3696	
33	3699	
34	3702	
35	3705	1st Advanced Class channel.
36	3708	
37	3711	
38	3714	
39	3717	

40	3720	
41	3723	
42	3726	
43	3729	
44	3732	
45	3735	
46	3738	
47	3741	
48	3744	
49	3747	
50	3750	
51	3753	
52	3756	
53	3759	
54	3762	
55	3765	
56	3768	
57	3771	
58	3774	
59	3777	
60	3780	
61	3783	
62	3786	
63	3789	
64	3792	
65	3795	
66	3798	
67	3801	
68	3804	1st General Class channel.
69	3807	
70	3810	
71	3813	
72	3816	
73	3819	
74	3822	
75	3825	
76	3828	
77	3831	
78	3834	
79	3837	
80	3840	
81	3843	
82	3846	
83	3849	
84	3852	
85	3855	
86	3858	
87	3861	
88	3864	
89	3867	
90	3870	
91	3873	
92	3876	

93	3879
94	3882
95	3885
96	3888
97	3891
98	3894
99	3897
100	3900
101	3903
102	3906
103	3909
104	3912
105	3915
106	3918
107	3921
108	3924
109	3927
110	3930
111	3933
112	3936
113	3939
114	3942
115	3945
116	3948
117	3951
118	3954
119	3957
120	3960
121	3963
122	3966
123	3969
124	3972
125	3975
126	3978
127	3981
128	3984
129	3987
130	3990
131	3993
132	3996
133	3999